

Instruction Manual NF-7XDT Series



- ◆ High temperature sensor / Low temperature sensor
- ◆ Differential-temperature output
- ◆ Alarm output

※ The purpose of this manual is to provide detail information to prevent damage cause by negligence. Please keep this manual properly for future reference. Regarding the English - language manual, please download it at our homepage.

1 Safety Precautions

Please read the instruction manual carefully for correct use.

※ The specification and dimensions provided in the instruction manual is subject to change without notice for product performance.

Warning

1. The product is not manufactured as a safety device; therefore, dual safety devices are required if the product is used as controlling devices or cases with concern of casualties or serious damage to the peripheral and significant property damage.
2. Do not perform wiring, inspection, and maintenance while power connected.
3. Terminal numbers must be checked when connecting power.
4. The equipment must not be disassembled, processed, improved, or repaired.

Caution

1. Please understand how to use, safety regulations, or warnings before the equipment is installed. The equipment must be used within the provisions and capacity provided in the manual.
2. Do not perform wiring and installation in motors with large inductive load and solenoid.
3. Use the same line when extending sensors and do not use excessive length.
4. Do not use parts that create an arc when switching nearby or the same power.
5. The power line should be away from high-tension power cables and avoid installation in areas with high moisture, oil, and dust.
6. Avoid installation in direct sunlight and areas exposed to rain.
7. Avoid installation in areas with high magnetic, noise, vibration, and impact.
8. The equipment should be installed sufficiently distant from strong alkali and strong acid substances.
9. When the equipment is installed in the kitchen, do not spray water directly onto the equipment for cleaning.
10. Do not install in places with high temperature/humidity that exceed the rate.
11. Care should be provided not to disconnect sensor cables or cause damage.
12. Sensor cables require significant distance from signal line, power, motive power, and load line and use independent pipes.
13. No warranty service shall be provided if the product has been altered or tampered with.
14. The mark on the wiring terminals is safety statement, such as warning or caution.
15. Do not use the product near machines that generate strong high-frequency noise (high frequency welding machine, high-frequency sewing machine, high-frequency radios, large SCR controller).
16. The product may cause injury or property damage if used for purposes not intended by the manufacturer.
17. Do not leave the product within reach of children as the equipment is not a toy.
18. Installation must be performed by professionals or qualified individual.
19. The company shall not be held responsible for any damage caused by negligence of consumers or due to non-conforming of the warnings or caution statements aforementioned.

Danger


- Caution, risk of electric shock

  1. Electric shock- Do not contact with AC terminal during current carrying. This may cause electric shock.
  2. Input power must be blocked when checking input power.

2 Model Composition

Model	Main Output	Input	Range	Power	Size	Function
NF-7PDT	Relay	PT100Ω	-199.9°C ~ 400.0°C	100~240 VAC	72(W)	Auxiliary Output
NF-7CDT	Relay	CA(K)	-50.0°C ~ 999.9°C	50/60Hz	72(H)	Relay
NF-7NDT	Relay	NTC 1KΩ	-20.0°C ~ 250.0°C			

3 Name of Part



◆ User mode change (Temperature settings)

Change of setting temperature of the main output  
 Pressing the # key once displays SET in the left FND and the setting value blinks/displays in the below FND.

or the set value by these keys, or move the set value to left/right by or key.


◆ Display selection

Pressing the \* key turns on No. 1 (HT) and No. 3 (LT) and displays high temperature and low temperature, or turns on No. 2 (DT) and No. 4 (SV) and displays differential temperature and set value.

◆ Installer Model Function Settings

Pressing the # key for 5 Sec. or more will display the menu name in the FND at the top and set value at the bottom FND. Up/down the set value by and key, or move the set value to left/right by or key.

4 Terminal Wiring



※ Relay connection capacity is 250VAC 2A or below. Care should be provided as the use of load that exceeds the capacity of the contact point may cause contact deposition, connection defect, and relay damage.

◆ Cold junction balancing circuit (CA sensor applied products)


An error occurs in thermoelectric power, in proportion to the ambient temperature, in the metals of input terminal and thermocouple sensor wires when the thermocouple sensor is contacted with the input terminal of temperature controller.

A contact balancing circuit is embedded to prevent the error.

◆ Extension wire (CA sensor applied products)


The extension wire is for extending the sensor line when the distance between the temperature controller and thermocouple sensors become longer. When the distance between the thermocouple and temperature controller becomes longer, the contact point of the thermocouple and regular wiring become a thermocouple sensor when extended with regular wiring, thereby creating error. To prevent the error, lines must be extended with metal wires similar as thermocouple metal wires. Extension wires have the red wire that refers to + polarity and blue (or white) that refers to - polarity.

Care should be provided when using extension wires not to connect opposite of + and - polarity to prevent error.



<Normal extension of sensor wires> <Abnormal extension of sensor wires>

5 External specification and panel processing dimension (Unit: mm)




6 Setting Range and Factory Set Value


Set Menu	Set Range			Factory Set Value		
	NF-7PDT	NF-7CDT	NF-7NDT	NF-7PDT	NF-7CDT	NF-7NDT
SEI	0.1~400.0	0.1~999.9	0.1~200.0	30.0	30.0	30.0
TYP	C/h	C/h	C/h	C	C	C
d t	00min 00sec ~ 19min 59sec			00min 00sec		
d f	0.1~50.0	0.1~50.0	0.1~50.0	1.0	1.0	1.0
Co1	-30.0~30.0	-50.0~50.0	-10.0~+0.0	0.0	0.0	0.0
Co2	-30.0~30.0	-50.0~50.0	-10.0~+0.0	0.0	0.0	0.0
ARS	D/ L/ HL/ H			D		
HPR	-199.9 ~ -400.0	-50.0 ~ -999.9	-20.0 ~ -200.0	400.0	999.9	200.0
LPR	-199.9 ~ -400.0	-50.0 ~ -999.9	-20.0 ~ -200.0	-199.9	-50.0	-20.0
ADF	0.1~50.0	0.1~50.0	0.1~50.0	1.0	1.0	1.0
DPR	0.1~400.0	0.1~999.9	0.1~200.0	30.0	30.0	30.0

7 How to Display

◆ High temperature / low temperature display



◆ Differential temperature / Setting display




Pressing the # switch for 2 seconds or longer while setting shows display characters while storing set value and shows the current temperature.

- \* How to choose display
- # Enter the set menu
- ▲ Increase set value
- ▼ Decrease set value
- ◀ Move setting digit to left
- ▶ Move setting digit to right



< Display (FND) Character Table >

0	1	2	3	4	5	6	7	8	9
A	B	C	D	E	F	G	H	I	J
K	L	M	N	O	P	Q	R	S	T
U	V	W	X	Y	Z				

8 Change of set value



9 Program settings



**dif** : A certain interval is required between ON and OFF in the hysteresis (variation) temperature interval setting On/Off control. (ON/OFF interval settings) If ON and OFF repeats too often the output point or relay will be damaged quickly or occurs hunting (oscillation or chattering) due to external noise. Setting the hysteresis (variation) temperature interval may prevent damage caused by contact or other machine malfunction aforementioned.

Setting example	typ : col (Cooling operation)	typ : het (Heating operation)
DIF: 3.0	Set : 5.0°C Dif : 3.0°C	Set : 5.0°C Dif : 3.0°C

**col1** : Current temperature calibration (high-temperature sensor)  
The function to adjust temperature if the temperature displayed on the panel of the equipment and actual temperature is different while there is no problem in the product. (Compare with water temperature thermometer or the thermometer in use)

e.g.) Actual Temperature: 25.0°C / Display panel: 28.0°C: If the temperature difference is 3°C compared with the actual temperature


Correct CO1.0 -> -3.0; the display panel will show 25.0°C

**col2** : Current temperature calibration (low-temperature sensor)  
The function to adjust temperature if the temperature displayed on the panel of the equipment and actual temperature is different while there is no problem in the product. (Compare with water temperature thermometer or the thermometer in use)


e.g.) Actual Temperature: 25.0°C / Display panel: 28.0°C: If the temperature difference is 3°C compared with the actual temperature  
Correct CO2.0 -> -3.0; the display panel will show 25.0°C

**ARS** : Alarm output selection

**H** : It operates when the high, low temperature is **HPR** set value or more



**HL** : The function operates if the high and low temperature is more than **HPR** set value or below **LPR** set value.




10 Change of set value

**typ** : MAIN(OUT1) integral domain settings (the cooling and heating selection function)


- If C is selected: Use as a cooler
- If H is selected: Use as a heater

**dlt** : Output motion delay time  
If the control object repeats ON/OFF operation and cause problems, the function protects the machine (cooler and compressor) from momentary power outage or power re-input.

**L** : The function operates when the high, low temperature is lower than **LPR** set value.



**D** : The function operates when the differential temperature is more than **DPR** set value.



**HPR** : Upper-limit alarm temperature settings  
The function sets temperature that operates when the temperature of the target, during controlling, increases more than **HPR**.

**LPR** : Lower-limit alarm temperature settings  
The function sets temperature that operates when the temperature of the target, during controlling, decreases more than **LPR**.

**a.d.f** : Hysteresis (variation) temperature interval settings of alarm output ON/OFF interval is set in order to prevent repeated ON/OFF alarm output.

**DPR** : Differential temperature alarm settings  
The function sets temperature that operates when the temperature of the target, during controlling, increases more than **DPR**.

11 Simple Troubleshooting

■ Error display while using the product

- Erj: Excessive noise is applied to the product and damaged the internal memory elements of data.
- Please contact the company for customer service.
- The controller has supplementary measures for noise but it cannot handle noise infinitely.
- Noise of more than 2KV may damage the product internally.
- Display of O-E (Open Error) or S-E (Short Error) means errors in the sensor. Please check the sensor.

※ The specification of the product is subject to change without prior notice for product improvement. Please be familiar with precautions necessary for handling the product.

※ Please download the English manual on our webpage.

■ H. Office : 56, Ballyongsandan 1-ro, Jangan-eup, Gijang, Busan, Republic of Korea  
■ Factory : 56, Ballyongsandan 1-ro, Jangan-eup, Gijang, Busan, Republic of Korea

■ TEL : +82-51-819-0426  
■ FAX : +82-51-819-4562  
■ e-mail : conotec@conotec.co.kr  
■ URL : www.conotec.co.kr

■ Main Production Products and Development  
- Digital temperature/humidity controller  
- Digital timer, current/voltage meta  
- Other product development

MEMO